



**Operating and Installation
manual for**

**PYRAMID DSP-T
10 - 250kVA**

Uninterruptible Power Systems

Important Notice

Thank you for purchasing Inform UPS.

This document provides instructions about safety, installation and handling of the UPS. It is necessary to read the manual completely before working on this equipment.



Read the manual completely before working on this equipment!



Keep this manual near UPS for easy consultation!

Symbols



This symbol points out the instructions which are especially important.



This symbol points out the risk of electric shock if the following instruction is not obeyed.



This symbol points out the instructions, which may be resulted with the injury of the operator or damage of the equipment if not obeyed.

Index

1	Safety	5
2	Installation	6
2nd1	Transportation	6
2nd2	Unpacking.....	6
2nd3	Storage.....	6
2nd4	Placement	6
2nd4.1	Environmental Requisites	6
2nd4.2	Electrical Requisites.....	7
2nd5	Connections	8
2nd5.1	Power Connections	9
2nd5.1.1	Protective Earth (Ground) Connections	12
2nd5.1.2	Input Connection	12
2nd5.1.3	Separated by-pass mains input connection (optional)	12
2nd5.1.4	External Battery Connection.....	12
2nd5.1.5	Output Connection.....	13
2nd5.2	Communication Interface Connections.....	13
3	Modes of Operation	14
3rd1	Bypass Mode	15
3rd2	Normal Mode	16
3rd3	Battery Mode.....	16
4	Control and Monitoring	17
4th1	Front Panel.....	17
4th1.1	Keypad.....	17
4th1.2	Mimic Panel	18
4th1.3	Liquid Crystal Display (LCD) and User Menu.....	19
4th1.4	Buzzer	22
5	Operating Procedures	23
5th1	Commissioning.....	23
5th2	Decommissioning	23
5th3	Switching into manual by-pass during operation	24
5th4	Returning from manual bypass to UPS.....	24
5th5	Connection to a generator.....	24
6	Operating Procedures for Parallel Systems	25
6th1	Introduction	25
6th2	Procedure for Commissioning and Start Up (First Installation)	25
6th3	Procedure for Transferring to Static Bypass	28
6th4	Procedure for Transferring to (Maintenance) Manual Bypass.....	28
6th5	Procedure for Switching OFF	28
7	Features and operating limits	29
7th1	Mains limits for normal operation	29
7th2	By-pass mains limits for bypass operation.....	29
7th3	Battery test.....	29
7th4	Overload behavior	30
7th5	Electronic short circuit protection.....	30

8	Communication	31
8th1	RS232 Communication	31
8th2	RS422 Communication	31
8th3	Digital Inputs (UPS OFF and GEN ON).....	32
8th4	Free Contact Communication	32
9	Maintenance.....	33
9th1	Battery fuses.....	33
9th2	Batteries	33
9th3	Fans	33
9th4	Capacitors	33
10	Troubleshooting.....	34
11	Technical Specifications	37

1 Safety



Information related to the safety of the UPS, loads and the user is summarized below. But the equipment should not be installed before reading the manual completely.



- ▶ The equipment may only be installed and commissioned by authorized technical persons.
- ▶ When the UPS is brought from a cold place to a warmer place, humidity of the air may condensate in it. In this case, wait for two hours before beginning with the installation.
- ▶ Even with no connections have been done, hazardous voltages may exist on connection terminals and inside the UPS. Do not touch these parts.
- ▶ Connect the PE ground connector before connecting any other cable.
- ▶ Do not put the battery fuses into the fuse holder before operating the equipment and seeing the “NORMAL” message on the LCD.
- ▶ The connections shall be made with cables of appropriate cross-section in order to prevent the risk of fire. All cables shall be of insulated type and shall not be laid out on the walking path of the persons.
- ▶ Do not expose UPS to rain or liquids in general. Do not introduce any solid objects.
- ▶ The equipment shall be operated in an environment, which is specified in “placement” section of this manual.
- ▶ Affix a label bearing the following expression, on the distribution panels feeding the UPS :
“Isolate the Uninterruptible Power Supply before working on this circuit”
- ▶ Do not plug the communication cables in or out during stormy weather.
- ▶ The equipment shall only be maintained and fixed by authorized technical persons.
- ▶ In case of an extraordinary situation (damaged cabin or connections, penetration of foreign materials into the cabin etc.) deenergize the UPS immediately and consult to the technical service.
- ▶ Replaced batteries must be disposed of at authorized waste disposal centers.
- ▶ Keep this manual near for easy consultation.
- ▶ The equipment shall be packed properly during transportation.
- ▶ The equipment is compliant with the European Community directives. Hence it is marked:



2 Installation

2nd1 Transportation

The UPS must remain in a vertical position throughout the transportation.

Make sure that the floor can support the weight of the system.

2nd2 Unpacking



Equipment and batteries whose packages are damaged during transportation shall be inspected by a qualified technical person before starting with the installation.

The procedure is as following:

- ▶ Remove the bands and the protective packaging from the UPS.
- ▶ Use suitable equipment to remove the UPS from the pallet.
- ▶ Mount the cabinet parts supplied with the UPS after positioning and connecting the UPS.



The equipment shall be packed properly during transportation. Therefore it is recommended to keep the original package for future need.

Check if the following are provided with the equipment

- ▶ Key of the cabin door
- ▶ Battery fuses (three pieces)
- ▶ Test report

2nd3 Storage

Recommended storage temperature, humidity and altitude values are listed on the “Technical specifications” section.

If the batteries will be stored for longer than 2 months, they shall be charged periodically. Charge period depends on the storage temperature. The relationship is as shown below:

- ▶ Every 9 months if the temperature is below 20 °C,
- ▶ Every 6 months if the temperature is between 20 °C and 30 °C,
- ▶ Every 3 months if the temperature is between 30 °C and 40 °C,
- ▶ Every 2 months if the temperature is over 40 °C

2nd4 Placement

2nd4.1 Environmental Requisites

This product meets the safety requirements for devices to be operated in restricted access locations according to EN 60950-1 safety standard, which states that the owner should guarantee the following:

- ▶ Access to the equipment can only be gained by service persons or by users who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken and,

- ▶ Access is through the use of a tool or lock and key, or other means of security and is controlled by the authority responsible for the location.

Recommended operating temperature, humidity and altitude values are listed on the “Technical specifications” section. Air conditioning may be required to provide these values.

Other requisites are:

- ▶ The equipment and the batteries shall not be exposed to direct sunlight or placed near to a heat source.
- ▶ Do not expose UPS to rain or liquids in general. Do not introduce any solid objects.
- ▶ Avoid dusty environments or areas where dust of conductive or corrosive materials is present.
- ▶ Air outlets of the UPS are on sides, front and back except 80kva ups. At 80kva the FANs are on the top side of the ups therefore there are no air inlets, outlets at the rear panel at 80kva. Leave at least 75 cm at the front and both sides and 50 cm at the back for maintenance and ventilation. At 80kva you do not have to leave any space at the rear part.

2nd4.2 Electrical Requisites

The installation must comply with national installation regulations.

The electrical distribution panels for the mains and separated by-pass mains inputs must have a protection and disconnection system. Disconnection devices used in these panels shall disconnect all line conductors and the neutral conductor simultaneously. The following table shows the recommended size of the mains and separate by-pass mains input protection devices (thermal, magnetic and differential) and the cable cross-sections for the linear loads.

UPS	Input thermal protection	Bypass mains input thermal protection	Input cable cross-section	Bypass mains input cable cross-section	Battery cable cross-section	Neutral Cable Cross section	Leakage current protection*
10 kVA (3Ph output)	25 A	25 A	6 mm ²	6 mm ²	6 mm ²	10 mm ²	30 mA
15 kVA (3Ph output)	25 A	25 A	6 mm ²	6 mm ²	6 mm ²	10 mm ²	30 mA
20 kVA (3Ph output)	40 A	40 A	10 mm ²	10 mm ²	10 mm ²	16 mm ²	30 mA
30 kVA (3Ph output)	63 A	63 A	16 mm ²	16 mm ²	16 mm ²	25 mm ²	30 mA
40 kVA (3Ph output)	80 A	80 A	16 mm ²	16 mm ²	16 mm ²	25 mm ²	30 mA
60 kVA (3Ph output)	100 A	100 A	25 mm ²	25 mm ²	25 mm ²	35 mm ²	30 mA
80 kVA (3Ph output)	125 A	125 A	35 mm ²	35 mm ²	35 mm ²	50 mm ²	30 mA
100 kVA (3Ph output)	160 A	160 A	35 mm ²	35 mm ²	35 mm ²	50 mm ²	30 mA
120 kVA (3Ph output)	200 A	200 A	50 mm ²	50 mm ²	50 mm ²	70 mm ²	30 mA
160 kVA (3Ph output)	250 A	250 A	70 mm ²	70 mm ²	70 mm ²	95 mm ²	30 mA
200 kVA (3Ph output)	315 A	315 A	95 mm ²	95 mm ²	95 mm ²	120 mm ²	30 mA
250 kVA (3Ph output)	400 A	400 A	120 mm ²	120 mm ²	120 mm ²	150 mm ²	30 mA

Input magnetic protection devices shall have D characteristic.

*Load leakage currents are added to those generated by the UPS. If loads with high leakage currents are present, adjust this value accordingly. It is recommended to adjust the protective device after measuring the total leakage current with the UPS installed and operational with the intended load.

During transitory phases (power failure, return and voltage fluctuations) short leakage current peaks may occur. Make sure that the protection is not activated in such cases.



If the loads have a nonlinear characteristic, the current on the mains input, separate by-pass mains input and output neutral conductors may have a value that is 1.5-2 times the phase value during operation. In this case, size the neutral cables and the input/output protection adequately.



According to EN 62040-1-2, the user shall place a warning label on the input distribution panel and the other primary power isolators, in order to prevent the risk of electric shock caused by a fault voltage on the UPS. The label shall carry the following wording:



Isolate uninterruptible power supply before working on this circuit

2nd5 Connections




Connections shall be done by authorized technical staff only.



When the UPS is brought from a cold place to a warmer place, humidity of the air may condensate in it. In this case, wait for two hours before beginning with the installation.

Layout of the connection terminals and boards are shown below:



A1: Communication interface board

A2: Parallel connection board (optional)

F1: Input circuit breaker

F2: Output circuit breaker

F3: Manual by-pass circuit breaker

F4: By-pass circuit breaker (optional)

F5: Battery circuit breaker

F6: Inrush fuse

X1: Battery terminals

X2: Input mains terminals

X3: Separate by-pass mains terminals (optional)

X4: Output terminals


2nd5.1 Power Connections




Devices with internal batteries may have dangerous voltages on the battery terminals

The power screw terminals are located on the lower front side of the UPS. Terminal details for ups's are shown separately in the below figures. Refer to the names of each terminal to identify it during connection:


10-15-20-30kVA (3ph-3ph) UPS Terminal Connections




40-60kVA UPS Terminal Connections




80-100kVA UPS Terminal Connections



120-160-200kVA UPS Terminal Connections



250kVA UPS Terminal Connections



Cables shall be passed through the hole under the connection terminals.

Make sure that all circuit breakers are “OFF”/”0” before starting with the installation.

Connections shall be done with the order below.

2nd5.1.1 Protective Earth (Ground) Connections



The device shall be earthed for a safe and reliable operation. Connect the PE ground connectors before connecting any other cable

Input protective earth connection terminal (PE) of the UPS shall be connected to ground with a low impedance connection.

PE terminals of the loads shall be connected to output protective earth terminal of the UPS.

If there is an external battery cabin present, it shall be grounded via battery protective earth terminal of the UPS.

2nd5.1.2 Input Connection



Bring the circuit breaker on the distribution panel to “OFF” or “0” position before making the connections

Connect the phases to input (X2) L1, L2 and L3 terminals.

A definite phase sequence is needed for the UPS to operate. If you encounter “TN SEQ FLR” alarm at start up, decommission the UPS, make the protection devices on the input distribution panels “0”/”OFF” and interchange any two phase cable.

Connect neutral to N terminal of X2.

2nd5.1.3 Separated by-pass mains input connection (optional)



Bring the circuit breaker on the distribution panel to “OFF” or “0” position before making the connections

Connect the phases to bypass (X3) L1, L2 and L3 terminals.

Make sure that the phases have the same sequence with the input supply.

Connect neutral to N terminal of X3.

2nd5.1.4 External Battery Connection



Do not put the battery fuses into the fuse holder (F5) before operating the equipment and seeing the “NORMAL” message on the LCD.



Devices with internal batteries may have dangerous voltages on the battery terminals

To connect external batteries, do the following:

- ▶ Switch the circuit breaker of the external batteries to “OFF” or “0” position.
- ▶ Connect the (-) pole of the external batteries to the battery (-) terminal,
- ▶ Connect the (+) pole of the external batteries to the battery (+) terminal,
- ▶ Connect the midpoint of the external batteries to the battery N terminal.



Danger of explosion and fire if the batteries of the wrong type are used.

2nd5.1.5 Output Connection



To enable the short circuit protection feature of the UPS, each load shall be fed over a separate circuit breaker chosen according to the load current. This may provide quick disconnection of the short circuited load and operation continuity of the other loads. To obtain maximum protection, the rating of each individual load circuit breaker shall have the minimum value, which is enough to carry the full load current continuously.



Rated apparent and active power of the loads shall be less than the UPS power ratings.

Connect the loads to output (X4) Line and N terminals.


2nd5.2 Communication Interface Connections

Related information is given in “communication” section.


3 Modes of Operation

There are three operation modes, which differ in the path of the energy flow.

UPS block diagrams and the energy flow path in each operation mode is shown below:



Block diagram without separate manual bypass input



Block diagram with separate manual bypass input

— Normal - - - Bypass mode Battery mode

When UPS has no separate bypass mains input, bypass line is also fed from the mains input. Thus, if such a device is in question, mains input shall be comprehended when the bypass mains input is referred in the following sections of the manual.

UPS behavior at the start-up is different from the usual operation. The UPS can only operate in bypass mode during start-up. So, in order for the UPS to start-up, frequency/waveform/rms value of the bypass mains voltage shall be in acceptable limits and bypass shall be enabled.

After start-up, the following applies:

Operation mode depends on the priority, inverter, rectifier and bypass preferences made by the user and mains, separate by-pass mains and battery voltages.

Priority and inverter, rectifier and bypass preferences can be set by using the COMMANDS and extra commands (EXTCMNDs) menus.

If operation in any of these modes is impossible, output voltage will not be present. In this case, loads will not be fed, and “VSECFLR” message is shown on the LCD instead of operation mode.

3rd1 Bypass Mode

Devices without separate bypass mains input, absorb energy from the mains. In devices with separate bypass mains input, energy is drawn from the separate bypass mains.

Loads are fed via static bypass line.

Output voltage has the same amplitude, frequency and waveform as the input voltage.

Current drawn by the loads are only limited by the thermal/magnetic switches over the energy flow path.

Voltage, frequency and waveform of the bypass supply shall be in their tolerance limits, and bypass shall be enabled for the UPS to operate in this mode.

When the upper provisions are met, the UPS works in bypass mode in the following conditions:

- ▶ During the start-up
- ▶ If the bypass priority is selected
- ▶ If the inverter is disabled or blocked
- ▶ In case of a prolonged overload

You can save energy by selecting the bypass priority. Efficiency in bypass mode is higher than the efficiency in normal mode. If the bypass priority is selected, the UPS will operate in bypass mode whenever the frequency/waveform/rms value of bypass mains voltage is in their tolerance limits. If the bypass voltage goes beyond these limits, the UPS switches into normal operation.



Bypass mode doesn't provide perfect stability in frequency/waveform/rms value of the output voltage like in normal mode. Thus, the use of this mode should be carefully executed according to the level of protection required by the application.



Bypass mode doesn't provide electronic short circuit protection like in normal mode. If a short circuit occurs on the output during bypass operation, the thermal/magnetic protection will act and all loads will be deenergized.



Prolonged overloads may cause the thermal/magnetic protection act. In this case, all loads will be deenergized.

3rd2 Normal Mode

Energy is drawn from the mains input.

Loads are fed via the rectifier and the inverter. The AC voltage at the input is converted to a DC voltage by the rectifier. The inverter converts this DC voltage to an AC voltage with a stable sinusoidal waveform, amplitude and frequency.

Output voltage is sinusoidal and has a regulated amplitude and frequency. It is independent from the input voltage.

The inverter is synchronized in frequency with the bypass mains input to enable load transfer to the bypass supply without any interruption, in case of an overload or inverter failure.

Voltage and frequency of the mains input shall be in their tolerance limits, and both the rectifier and the inverter shall be enabled for the UPS to operate in this mode.

When the upper provisions are met, the UPS works in normal mode in the following conditions:

- ▶ If the inverter priority is selected.
- ▶ If the bypass priority is selected but bypass is disabled or frequency/waveform/rms value of bypass mains voltage is not in acceptable limits.

3rd3 Battery Mode

Energy is drawn from the batteries. Loads are fed via the inverter.

Output voltage is sinusoidal and has a regulated amplitude and frequency. It is independent from the battery voltage.

Battery voltage shall be in acceptable limits and the inverter shall be enabled for the UPS to operate in this mode.

When the upper provisions are met, the UPS works in battery mode in the following conditions:

- ▶ If rectifier is disabled.
- ▶ If the rectifier is disabled or frequency/waveform/rms value of mains voltage is not in acceptable limits.

4 Control and Monitoring

4th1 Front Panel

The front panel located on the upper part of the UPS informs the user about operating status, alarm conditions and measurements. It also provides access to controls and configuration parameters.

Front panel shown below consists of three parts. As mimic panel provides basic information about the energy flow path and existing alarms, LCD (liquid crystal display) offers detailed information and provides access to controls. Keypad enables the user to move in the menu and to make selections.



4th1.1 Keypad

Functions of the buttons are given below:

BUTTON	SYMBOL	DEFINITION
ESC		Exit from the current menu
UP		Scrolls the available menus/values upwards. It increases the value each time it is pushed when changing a parameter.
DOWN		Scrolls the available menus/values downwards. It decreases the value each time it is pushed when changing a parameter.
ENTER		Enters the menu displayed on the screen. It makes selections or confirms the choice/changes made.


4th1.2 Mimic Panel

Mimic panel is a diagram, which shows the path of energy flow in the UPS by means of several LED's. Definitions of LED states are shown below:

LED's			
ID	COLOR	DEFINITION	STATE
Line 1	Green	Input mains voltage is OK and rectifier is active	Steady
		Input mains voltage is OK and rectifier is inactive	Flashing
		Input mains voltage is very close to its upper/lower limit and rectifier is active	
		Input mains voltage is not OK	Off
Line 2	Green	Bypass voltage is OK	Steady
		Bypass voltage is not OK and output voltage is synchronized to the bypass voltage	Flashing
		Bypass mains voltage is not OK and output voltage is not synchronized to the bypass voltage	Off
Battery	Red	Battery mode is active and battery voltage is OK	Steady
		UPS is performing battery test and battery voltage is OK	
		Battery mode is active and battery voltage is close to its lower limit (energy available in the battery is about to be depleted)	Flashing
		Battery test is active and battery voltage is close to its lower limit (energy available in the battery is about to be depleted)	
		Rectifier is active and able to supply whole power required by the inverter	Off
Inverter	Green	Load is fed via inverter	Steady
		Inverter is not active	Off
Load	Green	Load is powered	Steady
		Load is powered but UPS is overloaded	Flashing
		Output voltage is not OK	Off
Bypass	Yellow	Load is fed via static bypass line	Steady
		Bypass is not active	Off
Fault	Red	No alarms	Off
		A minor alarm is present	Flashing
		A major alarm is present	Steady

4th1.3 Liquid Crystal Display (LCD) and User Menu

LCD provides detailed information about device status, alarms and measurements. It also enables the operator to manage the UPS. All information, commands and configuration parameters are given in a menu, which has the following structure:



LCD consists of two lines and has the following structure:

"OPERATING MODE" or "VSECFLR" "MENU or PARAMETER NAME"

If there is no voltage on the output, VSECFLR message is displayed on the upper line.

Operation mode parameter is one of the notations below:

OPERATING MODE NOTATIONS	
NORMAL	Normal mode
BYPASS	Bypass mode
BATT	Battery mode

Menu and parameter descriptions are given below:

ALARMS MENU		
ALR	= "XXXXXXXXXXXX"	12 digit service codes.
ST	= "XXXX-XXXXXXXX"	Note these numbers before referring technical service.

Alarm codes and names can be seen by entering the ALR submenu.

CODE	NAME	DEFINITION
A01	BYP BADSHAPE	Bypass mains voltage is different than the inverter reference signal (e.g. its frequency is beyond synchronization limits or it has a total harmonic distortion > %10)
A02	BYP VOL HIGH	Bypass mains voltage is higher than its upper limit
A03	BYP VOL LOW	Bypass mains voltage is lower higher than its lower limit
A06	BYP SYN FAIL	Frequency of bypass mains voltage is beyond the frequency range for bypass operation or bypass mains voltage is very low
A07	BYP SEQ FAIL	Phase sequence of bypass mains voltages is not OK
A08	MNBYP SW ON	Manual bypass switch is "ON"
A09	INV TMP HIGH	Inverter block temperature is very high
A10	OUT OVERLOAD	RMS current drawn from any of the output lines exceeds its nominal value
A11	BYP ACT	Bypass is activated.
A12	INV NOT ACT	Inverter is not started due to a fault
A13	INV BLCK	Inverter operation is automatically stopped due to a fault
A14	VSEC NOT OK	Output voltage is beyond its limits
A15	MASTER T-OUT	This alarm is observed when information flow from master ups is interrupted
A16	CABLE UNPLUG	Parallel Communication cable is unplugged or damaged
A17	INP VOL HIGH	Input line/neutral voltage is higher than its upper limit
A18	INP VOL LOW	Input line/neutral voltage is lower than its lower limit
A21	INP SYN FAIL	Frequency of mains voltage is beyond the frequency range for normal operation or mains voltage is very low
A22	INP SEQ FAIL	Phase sequence of input mains voltages is not OK
A23	REC TMP HIGH	Rectifier block temperature is very high
A24	REC OVERLOAD	RMS current drawn from any of the input lines exceeds its nominal value
A25	VDC HIGH	DC bus voltages is higher than its upper limit
A26	VDC LOW	DC bus voltages is lower than its lower limit may mean that the battery is empty during battery operation
A27	REC NOT ACT	Rectifier is not started due to a fault
A28	REC BLCK	Rectifier operation is automatically stopped due to a fault
A30	TESTING BATT	Battery test is performed
A31	REDUND. LOST	It appears in case $\text{Load \%} \times (N+1) / N > 100$, for more information refer to page:28
A32	N FAULT	Depending on N description (n+1, n+2...), this alarm is observed when the qty of ups in the systems decreases below N value
A33	REC OFF	Rectifier is inactive
A34	INV OFF	Inverter is inactive
A35	BYP OFF	Bypass is inactive
A36	BYP PRI HIGH	Priority is Bypass
A37	BATT DISCHAR	Batteries are discharging after a mains failure
A38	VDC NOT OK	DC bus voltage is out of its normal range
A39	T-AMP HIGH	Ambient temperature exceeds its upper limit
A40	GENSET ON	Generator friendly operation is activated
A41	EMG STOP ON	Emergency stop is activated
A42	MINOR ALR	Minor Alarm
A43	MAJOR ALR	Major Alarm
A44	BATT TS FAIL	Batteries failed in the battery test

A45	BATT CR OPEN	Battery Circuit Breaker is open
A47	INV RX T-OUT	Communication between the inverter and the front panel is lost
A48	REC RX T-OUT	Communication between the rectifier and the front panel is lost

All alarms except VSEC NOT OK are minor.

MEASUREMENTS MENU		
MEASUREMENT		DEFINITION
LD	= XXX,XXX,XXX %	Ratio of the actual inverter active power of each line to its nominal value
Vsc	= XXX,XXX,XXX V	Output line/neutral voltages
Isc	= XXX,XXX,XXX A	Output line currents
Fo	= XX.X Hz	Frequency of output line/neutral voltages
Vby	= XXX,XXX,XXX V	Bypass line/neutral voltages
Vin	= XXX,XXX,XXX V	Input line/neutral voltages
Iin	= XXX,XXX,XXX A	Rectifier Output Current
Fin	= XX.X Hz	Frequency of input line/neutral voltages
Vdc	= XXX,XXX V	Positive and negative DC bus voltages
Vbat	= XXX,XXX V	Positive and negative battery branch voltages
Ibat	= ±XXX,±XXX A	Positive and negative battery branch currents Positive during charge, negative during discharge
Tbat	= XXX °C	Ambient temperature

COMMANDS MENU		
PRIORITY	= INVRTR/BYPASS	Selects the priority of normal and bypass operation modes Push ENTER to switch between INVRTR and BYPASS
START B. TEST		Push ENTER to start battery test
BUZZER	= ENBLD/DSBLD	Enable or disable the buzzer Push ENTER to switch between ENBLD and DSBLD
COMM	= RS232/RS422	Push ENTER to switch between RS232/RS422 communication
EXTCMNDS		Push ENTER 3 times to enter this submenu

EXTRA COMMANDS SUBMENU		
RECTFR	= ENBLD/DSBLD	Enable or disable operation of the rectifier block Push ENTER to switch between ENBLD and DSBLD
	= BLCKD*1	Can be seen only when the rectifier is blocked Push ENTER to remove the blockage and enable the rectifier
INVRTR	= ENBLD/DSBLD	Enable or disable the operation of the inverter block Push ENTER to switch between ENBLD and DSBLD
	= BLCKD*1	Can be seen only when the inverter is blocked Push ENTER to remove the blockage and enable the inverter
BYPASS	= ENBLD/DSBLD	Enable or disable the operation of the bypass thyristors Push ENTER to switch between ENBLD and DSBLD

*1 The UPS hinders the operation of the rectifier and inverter blocks in case of a failure.

CONFIGURATION MENU	
DATE = "XX-XX-XXXX"	Shows system date in dd-mm-yyyy format Push ENTER to switch between day, month, year, hour, minute and second. Then, use arrows to configure
TIME = "XX-XX-XX"	Shows system time in hh-mm-ss format Use date submenu to set time

EVENTS MENU	
EVENTS (xxx)	Shows last 380 events (alarms) of system. (xxx) shows events count. To look event details, you must press ENTER key in current position and use UP/DOWN keys.
CLEAR EVENTS	Clears all events stored in eeprom after verification of clear process.

EVENTS (xxx) SUB MENU	
YYY : AAAAAAAAAAAAAA	“YYY” Shows order number of event and “AAAAA-A” shows event description. (For events descriptions see ALARM DEFINITIONS on page 17). Events stored in eeprom using FIFO method. Order number of last occurred event is 001. To look event details, you must press ENTER key in current position and use UP/DOWN keys.
DATE = XX/XX/XXXX	Displays date of event occurring.
TIME = XX:XX:XX	Displays time of event occurring.
A:XXXX-XXXX-XXXX	Displays alarm status when event is occurred.
ST=XXXX-XXXXXXXXXX	Displays status string when event is occurred.

IDENTIFICATION MENU	
"X/X XXX kVA"	Shows number of input/output phases and output nominal apparent power
FW = "XX"	Shows firmware version

4th1.4 Buzzer

Buzzer warns the user about the present alarms. It can be disabled by using the commands menu

BUZZER	
STATE	DEFINITION
Off	No alarms
Discontinuous	A minor alarm is present
Steady	A major alarm is present

5 Operating Procedures

This chapter defines the operating procedures to be followed to activate, deactivate and manage the UPS. The instructions shall be applied with the sequence, in which they are written.

5th1 Commissioning

Make the connections according to the installation section.

Switch the circuit breaker on the input distribution panel “ON” / “I”.

Switch the circuit breaker on the by-pass distribution panel “ON” /”I”.

If the by-pass mains input is separated, bring the by-pass circuit breaker (F4) to “ON”/ “I” position.

Bring the input circuit breaker (F1) and inrush circuit breaker (F6) to “ON”/ “I” position.

Bring the output circuit breaker (F2) to “ON” / “I” Position.

Wait for the LCD to start up. Set the date and time.

See the “NORMAL” message on the LCD.

Bring the circuit breaker of the external battery cabinets to “ON”/ “I” position.

Bring the battery circuit breaker (F5) to “ON”/”I” position.



The UPS starts up in bypass mode and automatically switches to normal mode. “NORMAL” message will not be displayed, until the UPS switches to normal mode. Frequency/waveform/rms value of the bypass mains voltage shall be in acceptable limits and bypass shall be enabled for the UPS to start-up. Voltage and frequency of the mains input shall be in their tolerance limits, and both the rectifier and the inverter shall be enabled for the UPS to operate in normal mode.

5th2 Decommissioning

Bring the output circuit breaker (F2) to “OFF”/”0” position.

Bring the input, inrush and manual by-pass circuit breakers (F1, F6 and F3) to “OFF”/”0” position.

If the by-pass mains input is separated, bring the by-pass circuit breaker (F4) to “OFF”/”0” position.

Bring the battery circuit breaker (F5) to “OFF”/”0” position.

Bring the circuit breaker of the external battery cabinets to “OFF”/”0” position.

Switch the circuit breaker on the input distribution panel “OFF” / “0”.

Switch the circuit breaker on the by-pass distribution panel “OFF” / “0”.



In the event of an extended period of UPS inactivity, the batteries must be charged periodically in order to prolong battery life. The charge period, which depends on the temperature, is given in the “storage” section of the manual.

5th3 Switching into manual by-pass during operation

Manual by-pass enables the user to isolate the electronic circuitry of the UPS from the mains and the load without interrupting the load operation by connecting the loads directly to the bypass supply.

This feature is useful while performing maintenance or service and shall only be executed by authorized technical service personnel.



Maintenance and service may only be performed by authorized technical personnel

Bring the manual bypass circuit breaker (F3) to “ON”/ “T” position.

Make sure that the UPS switches into bypass mode (see “BYPASS” message on the LCD). Voltage, frequency and waveform of the bypass mains shall be in limits, and bypass shall be enabled for the UPS to operate in bypass mode.

Bring the input and inrush circuit breakers (F1 and F6) to “OFF”/”0” position.

If the by-pass mains input is separated, bring the by-pass circuit breaker (F4) to “OFF”/”0” position.

Bring the output and battery circuit breakers (F2 and F5) to “OFF”/”0” position.

LCD and buzzer will stop operation in a few minutes.



During manual bypass operation, loads are fed directly from bypass mains. Therefore no protection against mains disturbances or interruptions is present.



Although all switches except F3 is “OFF” during manual bypass operation, hazardous voltages are present on the terminals, EMC filters and measurement circuits.

5th4 Returning from manual bypass to UPS

Bring the output circuit breaker (F2) to “ON”/”T” position.

Bring the input and inrush circuit breakers (F1 and F6) to “ON”/ “T” position.

If the by-pass mains input is separated, bring the by-pass circuit breaker (F4) to “ON”/ “T” position.

Bring the manual bypass circuit breaker (F3) “OFF”/”0” position.

See the “NORMAL” message on the LCD.

Bring the battery circuit breaker (F5) to “ON”/ “T” position.

5th5 Connection to a generator

If the input power is supplied by a generator, set the digital input “GEN ON” high. This ensures generator friendly operation by smoothing the increment of the current drawn from the generator, during transition from battery mode to normal mode.

When this is done, “GEN ON” alarm will be shown. Connection details are given in the “communication” section.

6 Operating Procedures for Parallel Systems

6th1 Introduction


Pyramid DSP T UPS Systems are designed according to high MTBF figures with increased reliability but in case of necessity, a second (or more) Pyramid DSP T UPS's can be connected in parallel redundant configuration for supplying the very critical load to increase the reliability. Maximum 4pcs identical power and specification Pyramid DSP T can be connected in parallel.

If power demand increases in a certain UPS application exceeding the power rating of an already installed stand-alone UPS, then a second (or more) UPS of the same model and power rating can be added in parallel to the existing UPS to increase the output power capacity.

The AC inputs of all UPS's in the parallel system are connected to the same mains, and all the AC outputs are connected to each other. Each UPS has its own battery group. The critical load is connected to the common output of the parallel system. There are also some signal cable connections between the UPS units necessary for parallel operation, and will be described later.


6th2 Procedure for Commissioning and Start Up (First Installation)

- 1) If the UPS's will be converted to parallel systems on site, after installing the parallel kit to each ups, calibration of them should be made perfectly at single mode initially.
- 2) Before switching on the ups's, make sure that electrical connections have been made as shown in below diagram:



(OUTPUT CONNECTION OF PARALLEL UPS SYSTEMS)

3) The Communication of parallel systems is made through CANBUS. Before starting up the UPS's, make the connection of communication cables between UPS's as per below diagram:



(COMMUNICATION CABLE CONNECTION BETWEEN PARALLEL UPS's)

CAUTION: Do not remove the communication cables between the UPS's during parallel operation.

In case this communication cable is removed or damaged during parallel operation and the communication is lost then the slave ups which can not communicate with the master ups shall disenergize its output and maintain the OFF position. The other ups's shall continue their normal operation. At such a case, this UPS should be turned off completely in order to insert its communication again and then switched on again. Do not try to insert its communication cable while it is operating.

3) All switches (F1, F2, F3, F4(optional), F5 and F6) should be in “OFF” (“0”) position.

4) Switch on the input Fuse (F1) of the first UPS (“Master” or “Number 1” labeled UPS) , Inrush Fuse (F6) should be in “OFF” position. (Note: if the ups's are not factory parallel configured, then any of the ups can be switched on but followingly should be configured as master and the remaining UPS's as slave which will be explained in detail in the following section)

5) Go to the “CONFIGURATION” section from the front panel menu, enter to “MODE” part and change it from SINGLE to PARALLEL-1 position. This adjustment is made already at factory set UPS's. Then please check and control this during commissioning.

6) By using down button on the same Menu, “N” number should be defined. Parallel Pyramid DSP T series UPS's operate according to redundancy principle. At the N+1 configurations, the “N” number in this part is usually - 1 quantity of the parallel operating ups qty.

On each UPS, this value should be same and correctly entered. Consequently the amount of load that is allowed to be connected to total system should not be more than (UPS qty – N).

“N” can be defined different than “1”. For example it can be defined as 2 at a 4pcs parallel system.

In this case the system will operate as 2+2 redundancy mode and the total load that is going to be connected to the system can not be more than (2x One UPS Power).

N Value here can be accepted as minimum UPS qty that is required to supply the load where each ups operates in full load condition. Then (UPS Qty) – (N) becomes the redundant ups qty in the system.



The system expect to have at least one more ups than N value. Otherwise it shall provide “REDUNDANCY LOST” alarm. The same alarm shall also appear in case

Load % x (N+1) / N > 100 situation.



“Redundancy Lost” alarm is just a warning alarm stating that the load amount shared on the remaining ups's is more now, after the failure of one ups or after a power increase on the load side. This alarm shall not affect the normal operation of the total system. It indicates that there is not anymore redundant ups in the total system. In case of a failure on one of the remaining ups's, the system will either go to overload, bypass condition or will shut down totally depending on the ups quantity in the parallel system.

7) After defining the UPS number and N value from the Configuration Menu, switch off the UPS and similarly configure the other parallel UPS's in the system. Followingly switch off each ups again. Each ups number should be different. Under this menu; Parallel-1, Parallel-2, Parallel-3 and Parallel-4 options are available. Maximum 4pcs of UPS can be connected in parallel and at the systems where 4 UPS's operate in parallel, each ups's numbers should be different, defined from 1 to 4. (note: if the ups's are factory parallel configured then each ups's number has been already defined, please check and control this)

CAUTION: Configuring the parallel ups's with same numbers may cause serious damage during operation. Make sure that each parallel ups is configured with different numbers.

8) After completing the configuration the Numbers of each ups and N values, switch on the F1 input fuse then F4 Bypass Fuse (if the ups is splitt bypass version) and F6 Inrush Fuse respectively on each parallel UPS's.

After seeing "Normal" message on the LCD panel, F5 Battery fuse can be switched on.

Then the output fuses can be switched on followingly.

The system (all ups's in parallel configuration) will start operating from static bypass initially, then they will start supplying the load from inverter.

9) The initially started up UPS will operate as master and the remaining UPS's will operate as slave. According the numbers defined for each ups, on the LCD panel, MAS (master) and SLAVE (1,2,3,4) messages should be observed. On the master unit, candidate master ups is also shown as CX.

C represents the best available master candidate ups among the slave ups's and X represents the number of the slave UPS. In case the master ups fails, then this candidate assigned UPS becomes master.

6th3 Procedure for Transferring to Static Bypass

In case it is required to transfer the system to Static Bypass, then this process can be made from the LCD panel of any ups in the parallel system. In case static Bypass is activated on any UPS, all the UPS's will pass to Static Bypass mode at the same time.

In order to pass to static bypass mode, From the LCD panel menu, go to Commands Menu – Extcmd.

Select the SYS. TO BYP : ENBLD from the menu. In order to do this selection, pressing ENTER button will be enough. If Enter button is pressed again from any ups in system (not need to be done from the ups where it was enabled at the first time) , then the selection will be changed to DSBLD (static bypass disabled, again inverter operation starts).

6th4 Procedure for Transferring to (Maintenance) Manual Bypass

In case it is required to transfer the system to Manual Bypass, then this process can be made from any ups in the system. In case Manual Bypass is activated on one of the any UPS, other UPS's will enter to Static Bypass mode also.

In order to activate the Bypass Mode, it is enough to switch on the Maintenance Bypass switch (F3) on any UPS.

To go back to Inverter operation again, it is necessary to switch off the manual bypass switch of the ups which is brought to on position at the first place.

6th5 Procedure for Switching OFF

To switch off the System or one of the ups, follow up the below procedures;

- 1) Switch off the Battery Fuse (F5)
- 2) Switch off the Output Fuse (F2)
- 3) Switch off the Input Fuse (F1) and Inrush Fuse (F6)
- 4) Switch off the Bypass Fuse (F4) if exists

Now the ups or ups's can be separated from the system.

7 Features and operating limits

7th1 Mains limits for normal operation

Frequency and rms value of the mains input voltage has to be between acceptable limits for the UPS to operate in normal mode.

Lower limit of the voltage depends on how much the UPS is loaded and it decreases as the load decreases until it reaches 80 V phase-neutral.

Frequency lower and upper limits and voltage upper limit are fixed.

Voltage and frequency ranges for normal operation are given in the “technical specifications” section of the manual.

This feature lessens the need to use the batteries. Thus, it increases the battery life and continuity of the load power.

7th2 By-pass mains limits for bypass operation

Frequency, rms value and total harmonic distortion of the bypass mains input voltage has to be between acceptable limits for the UPS to operate in bypass mode.

Different rms voltage upper and lower limits are present for the return from another operation mode to bypass mode. This provides hysteresis and ensures that the device does not change operation mode very often when the bypass mains rms voltage is close to one of the limits.

Bypass mains limits are software parameters. They can be changed upon request.

7th3 Battery test

This feature enables the user to obtain information about the battery condition. If the batteries have approached end of their lives, batteries fail.

Battery life depends on several parameters like the number of charge-discharge cycles, discharge depth and ambient temperature. Battery life greatly decreases as the ambient temperature increases. Therefore it is recommended to keep the ambient temperature about 20 °C.

To perform a battery test, enter “START B. TEST” in the COMMANDS menu and wait. The UPS will switch into battery mode, when the test has started. After about ten seconds, UPS will return to the operation mode before the test. If the batteries pass the test, no alarm will be shown.

If the batteries fail, you’ll receive BATT FAILED message under the ALR submenu. In this case, make sure that the battery circuit breaker is “ON”/”I”, charge the batteries for minimum 10 hours and repeat the test. If the alarm persists, consult technical service for replacement.



Make sure that the batteries are fully charged and battery circuit breaker is “ON”/”I” before starting battery test. Otherwise, the batteries will fail even if they are in good condition.

BATT FAILED message will not disappear until another successful test is performed.

7th4 Overload behavior

While operating in normal or battery mode, the UPS can feed overloads for a limited duration which is given in the “technical specifications” section. After that duration, UPS automatically switches into bypass mode, if the bypass is enabled and frequency/waveform/rms value of the bypass mains voltage is acceptable. If the overload situation continues in the bypass operation, thermal/magnetic protection devices may activate and protect the circuit. In this case, all loads on the output will be deenergized.



Make sure that the UPS is not overloaded to provide a higher quality supply to the loads.

7th5 Electronic short circuit protection

The UPS attempts to force the thermal/magnetic protection devices between the output terminals and the short circuited load to open, by supplying current to the short circuited load for a limited duration. The UPS shall be working in battery or normal mode, for this feature to work.




To enable the short circuit protection feature of the UPS, each load shall be fed over a separate circuit breaker chosen according to the load current. This may provide quick disconnection of the short circuited load and operation continuity of the other loads. To obtain maximum protection, the rating of each individual load circuit breaker shall have the minimum value, which is enough to carry the full load current continuously.

If the protection device fails to open the circuit in a limited time, the UPS stops feeding current to the output. “VSECFLR” message is shown on the upper left of the LCD.

8 Communication

All related terminals are on the communication interface board (A1). Connector layout is as following:



8th1 RS232 Communication

DSUB-9 female connector with the following pin layout shall be used on the UPS side of the connection cable.

Pin layout is given below:

RS232 PIN LAYOUT		
Pin #	Signal Name	Signal Description
2	RX	Receive data
3	TX	Transmit data
5	GND	Signal ground

RS232 cable shall be shielded and shorter than 15 m.

Only one of the RS232/RS422 communications can be activated at one time. The selection between RS232 and RS422 communications can be done by setting the COMM parameter in COMMANDS menu, as desired.

8th2 RS422 Communication

DSUB-9 male connector with the following pin layout shall be used on the UPS side of the connection cable.

Pin layout is given below:

RS422 PIN LAYOUT		
Pin #	Signal Name	Signal Description
6	A	Receive signal pair
5	B	
1	Z	Transmit signal pair
9	Y	
4	GND	Signal ground

RS422 cable shall be shielded and shorter than 100 m.

Only one of the RS232/RS422 communications can be activated at one time. The selection between RS232 and RS422 communications can be done by setting the COMM parameter in COMMANDS menu, as desired.

8th3 Digital Inputs (UPS OFF and GEN ON)

Voltage to be applied to the digital inputs is 5V DC. Maximum current drawn by each input is 1 mA. 5V DC supply provided on the communication interface board can be used to supply both digital inputs.



Pay attention to the polarity of the voltages applied to the digital input terminals.

Input	Function
UPS OFF	If the UPS OFF input is set high by applying 5V DC voltage on the related terminals, UPS stops generating the output voltage and stops feeding the load. When the voltage on the digital input is removed, the UPS starts up according to the normal procedure.
GEN ON	If the GEN ON input is set high by applying 5V DC voltage on the related terminals, UPS smoothly increases the current drawn from the generator during transitions from battery mode to normal mode.

8th4 Free Contact Communication

Free contact relay connection cables shall have a cross-section of 1.5 mm².



Maximum voltage to be applied to the relay contacts is 42V AC rms (sinus) or 60 Vdc. Maximum contact current depends on the applied voltage and the load characteristic. Both maximum voltage and maximum contact current corresponding to the applied voltage shall not be exceeded.

Maximum allowed resistive contact currents for several voltages are given on the table below:

Applied voltage	Maximum contact current for resistive load
Up to 42 V AC	16 A
Up to 20 V DC	16 A
30 V DC	6 A
40 V DC	2 A
50 V DC	1 A
60 V DC	0.8 A

Each relay has both a normally open (NO) and a normally closed (NC) contact. One end of these contacts is common. Normal states of the relay contacts are shown on the figure at the beginning of the “communications” section.

Relay functions are described below:

Relay	Function
ACFR (AC failure relay)	Contacts change position if the rms value or frequency of the mains voltage is beyond their limits.
BYPR (Bypass relay)	Contacts change position if the UPS is working in the bypass mode
BUVR (Battery under voltage relay)	Contacts change position if the battery voltages are critically low to feed the load and the load power is about to be interrupted
SBFR (secure bus failure relay)	Contacts change position, if the output voltage disappears

9 Maintenance

Batteries, fans and capacitors shall be replaced at the end of their lives.



Hazardous voltage and high temperature metal parts inside even if the UPS is disconnected. Contact may cause electric shock and burns. All operations except replacing battery fuses shall be carried out by the authorized technical personnel only.



Some parts inside the UPS (terminals, EMC filters and measurement circuits) are still energized during maintenance bypass operation. In order to deenergize all UPS parts, circuit breakers on mains and bypass mains distribution panels feeding the UPS and circuit breakers on external battery cabinet shall be brought to “OFF/0” position. Internal batteries shall also be isolated from the system.

9th1 Battery fuses

Bringing the battery circuit breaker to “T”/“ON” position before seeing “NORMAL” message on the LCD may cause battery fuses to blow out.



Battery fuses shall only be replaced with Gould 22x58 aR 660V ultra fast fuse of same rating or equivalent.

9th2 Batteries

Battery life strongly depends on the ambient temperature. There are also other factors like the number of charge-discharge cycles and discharge depth.

Battery life is between 3-10 years if the ambient temperature is between 10 – 20 °C. Performing battery test can provide you information about battery condition. (See “battery test” section for more information on battery test)



Danger of explosion and fire if the batteries of the wrong type or number are used.



Do not dispose of batteries in a fire. The batteries may explode. Do not open or mutilate batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.

9th3 Fans

The life of fans used to cool the power circuits depends on the usage and environmental conditions. Preventive replacement by authorized technical personnel every four years is recommended.

9th4 Capacitors

The life of the electrolytic capacitors on the DC bus and the capacitors used for output and input filtering purposes depends on the usage and environmental conditions.

Preventive replacement by authorized technical personnel every five years is recommended.

10 Troubleshooting

This section gives information about the procedures which shall be performed in case of abnormal operation. If you fail to fix the problem consult authorized technical service with the following information:

- ▶ Model and serial number of the UPS, which can be found on the nameplate on the rear of the UPS. This information is also available in the test report provided with the UPS.
- ▶ ALR and ST codes in the ALARMS menu



Hazardous voltage and high temperature metal parts inside even if the UPS is disconnected. Contact may cause electric shock and burns. This unit is to be served by authorized technical personnel only.

Alarms and problems you may encounter during operating the UPS are given in the table below.

If you have noticed an abnormality in operation; check the protective earth connections, examine the circuit breaker positions, read alarms from the ALARMS menu and refer to the table. Apply all suggestions corresponding to each alarm. If your issue is excluded or the suggested actions do not solve your problem, consult the technical service.

Alarm	Possible Cause	Action
BYP BAD alarm is present	Bypass mains voltage is different than the inverter reference signal	Make sure that the bypass circuit breaker is "I"/"ON"(if the UPS has no separate bypass mains input, make sure that the input circuit breaker is "I"/"ON".
	(e.g. its beyond its limits or it has a total harmonic distortion > %10)	
VBYP HIGH alarm is present	Bypass mains voltage is higher than its upper limit	Check if the bypass mains voltage is in specified limits
VBYP LOW alarm is present	Bypass mains voltage is lower higher than its lower limit	
BYP SYN FL alarm is present	Frequency of bypass mains voltage is beyond the frequency range for bypass operation or bypass mains voltage is very low	
BYP SEQ FL alarm is present	Phase sequence of bypass mains voltages is not OK	Phase sequence of the separate bypass mains input shall be changed. Consult technical service
MAN BYP alarm is present	Manual bypass switch is "ON"	Check the position of the manual bypass switch.
INV OVTE alarm is present	Inverter block temperature is very high	Check if there is an overload and remove the excessive load. Measure the ambient temperature near UPS. Make sure that the temperature is in specified limits. Check if the fans are running.
OUT OVLD alarm is present	Rms current drawn from any of the output lines exceeds its nominal value	Check if there is an overload and remove the excessive load. If the total power drawn by the load is less than the nominal power, make sure that it is distributed evenly between phases.

Alarm	Possible Cause	Action
INV BLKD alarm is present	Inverter operation is automatically stopped due to a fault	Consult the technical service
VSEC NOK alarm is present (Output voltage is beyond its limits)	The UPS may not started up yet. This alarm is permanent if the UPS is intended to be started with the bypass blocked or when the bypass mains is not in specified limits	Make sure that all circuit breakers is "I"/"ON" Check if there is any other alarms and apply the related suggestions Examine the preferences, check the mains voltages and read the "modes of operation" section of the manual. Determine if the combination of line voltages and preferences does inhibit the UPS operation.
	The UPS may have stopped to feed the load because the combination of the mains conditions and the user preferences made from the COMMANDS menu does not allow the UPS to work in any of the operation modes.(e.g. if inverter is disabled and both input and bypass mains voltages are not acceptable or if the rectifier is disabled when the bypass voltage is not in specified limits or batteries may be discharged during a prolonged outage)	
	The output circuit breaker is "0"/"OFF"	
VIN HIGH alarm is present	Input line/neutral voltage is higher than its upper limit	Check if the bypass mains voltage is in specified limits
VIN LOW alarm is present	Input line/neutral voltage is lower than its lower limit	
IN SYN FLR alarm is present	Frequency of mains voltage is beyond the frequency range for normal operation or mains voltage is very low	Check if the mains voltage is in specified limits
IN SEQ FLR alarm is present	Phase sequence of input mains voltages is not OK	Phase sequence of the mains input shall be changed. Consult technical service
RECT OVTE alarm is present	Rectifier block temperature is very high	Measure the ambient temperature near UPS. Make sure that the temperature is in specified limits. Check if the fans are running.
RECT OVLD alarm is present	RMS current drawn from any of the input lines exceeds its nominal value	Check if there is an overload and remove the excessive load.
VDC HIGH alarm is present	Any of the DC bus voltages is higher than its upper limit	Consult the technical service
VDC LOW alarm is present	Any of the DC bus voltages is lower than its lower limit Means that the batteries had discharged. It is removed when the rectifier resets.	If you encounter this alarm during start-up, check if the inrush circuit breaker is "ON"/"I".
		Charge the batteries, perform battery test and check if the alarm has removed.
RECT BLKD alarm is present	Rectifier operation is automatically stopped due to a fault	Consult the technical service

Alarm	Possible Cause	Action
VDC NOK alarm is present	Any of the DC bus voltages approaches its lower or upper limits May mean that the batteries have approached to their lower voltage limit and are almost empty.	Charge the batteries, and check if the alarm has removed.
AMB OVTE alarm is present	Ambient temperature exceeds its upper limit	Measure the ambient temperature near UPS. Make sure that the temperature is in specified limits.
GEN ON alarm is present	Generator friendly operation is activated (digital input "GEN ON" is set high)	Check the "GEN ON" input
UPS OFF alarm is present	Emergency stop is activated (digital input "UPS OFF" is set high)	Check the "UPS OFF" input
BATT FAILED alarm is present	Batteries failed in the battery test	Perform the test again when the batteries have been charged for a long time and the battery circuit breaker is "I"/"ON" Check if the alarm continues
BATT C. OPEN alarm is present (A difference between battery & DC bus voltage is present)	Battery circuit breaker (F5) is probably open ("0"/"OFF")	Make sure that the battery circuit breaker is "I"/"ON". If not do the following: -Check the rectifier preference and enable the rectifier. -Make sure that the input mains voltage is in specified limits. -Make sure that the UPS has switched to normal mode and close the battery circuit breaker.
	The battery circuit breaker of the external battery cabinet is open ("0"/"OFF")	Make sure that the battery circuit breaker of the external battery cabinet is "I"/"ON". If not do the following: -Check the rectifier preference and enable the rectifier. -Make sure that the input mains voltage is in specified limits. -Make sure that the UPS has switched to normal mode and close the battery circuit breaker.
	Battery fuses of the battery circuit breaker (F5) or the external battery cabinet may have blown	Check if the battery fuses are blown. Replace if necessary (see maintenance section)
	There is no battery in the system	Batteries shall be supplemented. Consult technical service

11 Technical Specifications

MODELS													
Apparent power [kVA]	10	15	20	30	40	60	80	100	120	160	200	250	
ENVIRONMENTAL													
Storage temperature range [°C]	-25 to +55 (15 - 40 recommended for longer battery life)												
Operating temperature range [°C]	0 to +40 (20 - 25 recommended for longer battery life)												
Relative humidity range	% 0 - % 95 (non condensing)												
Max. altitude without derating [m]	1000												
Protection level	IP 20												
ELECTRICAL													
Mains Input													
Number of phases	3P+N+PE												
Nominal voltage [V]	380 / 400 / 415 (line-line)												
Voltage range for normal operation (line to neutral) [V]	Lower limit (depends on the load level)	187 @ %100 load (line- neutral)											
		120 @ %64 load (line- neutral)											
		80V@ %42 load (line- neutral)									-		
	Upper limit	280											
Nominal frequency [Hz]	50 / 60												
Frequency range [Hz]	+/-10%												
Nominal current [A]	wave form	sinusoidal											
	rms value *(2)	13	20	26	40	53	79	105	131	158	211	263	328
Maximum current [A]	wave form	sinusoidal											
	rms value	17	23	30	47	61	95	125	158	195	260	325	406
OUTPUT													
Performance classification according to IEC 62040-3	VFI-SS-111												
Number of phases	3P+N+PE												
Nominal voltage [V]	380 / 400 / 415 (line-line)												
Static voltage regulation	normal	<%1											
@ %100 linear load	battery												
Nominal frequency [Hz]	50 / 60												
Free running frequency [Hz]	± % 0.01												
Voltage THD @ rated linear load	<%1.5%												
Nominal apparent power [kVA]	10	15	20	30	40	60	80	100	120	160	200	250	
Maximum load p. f.	0.8												
Nominal active power [kW]	8	12	16	24	32	48	64	80	96	128	160	200	
Nominal current [A] at 380V	15.2	22.7	30.3	45.5	60.6	91	121	151	181	241	302	377	
Load crest factor @ rated power	3:1												
Overload duration	>1min @ %150 load												
Efficiency (normal operation) @rated linear load with 0.8 PF	Up to 91% *												

STATIC BY-PASS LINE												
Number of phases	3P+N+PE											
Voltage range (line- neutral) [V]*(1)	220 V /230V /240V ±%10											
Frequency range [Hz] *(1)	47-53											
Nominal apparent power [kVA]	10	15	20	30	40	60	80	100	120	160	200	250
Nominal current [A]	15.2	22.7	30.3	45.5	60.6	91	121	151	181	241	302	377
Transfer duration [ms]	0											
BATTERIES												
Battery type	Sealed lead acid, 12 V											
Number of batteries	2x27											
Nominal battery voltage [V]	2x324											
STANDARDS												
Safety	EN 62040-1-2, EN 60950-1											
Performance	EN 62040-3											
EMC	EN 50091-2											
Product Certification	CE											
COMMUNICATIONS												
Free contact communication (AC failure, battery under voltage, bypass and output failure)												
Serial communications (RS232, RS 422)												
Two digital inputs for remote shut down of the UPS and generator operation feedback												
Isolated auxiliary 5V supply for digital inputs												
OTHERS												
Manual by-pass with 0 transfer time												
Electronic short circuit protection												
Over temperature and over current protection												
Liquid crystal display (LCD)												
Mimic front panel												

*(1) These are software parameters. They can be changed upon request

*(2) Batteries shall be fully charged in order to provide these values

* this parameter may vary depending on ups power